



## PARTY PRINTING 101 for Hosts

With your printer all set up and ready to go, here are some tips for printing at the party!

### Wireless Printing

Print & fill-out the Wi-Fi® party favor, and display it so your guests can easily connect. Remind everyone that if they want to print from their compatible phones, tablets, or laptops they need to connect to the wireless network!

*TIP: Ask guests to say what they are printing before they hit "print". This way you can make sure the right paper is loaded and helps prevent everyone trying to print at the same time.*

*TIP: If there are last minute Wi-Fi connection issues you can connect to the printer via Bluetooth<sup>2</sup>, if available. Look up "Printing/Scanning with Wireless Direct" in the printer User Manual for instructions.*

### Paper Loading

Use the rear tray during the party to easily switch out different papers and printable materials. Don't forget to choose the paper type and size on the screen (it should pop up on the screen when you change paper).

*TIP: Keep plain letter size paper in the cassette.*

### Pre-party Guest Prep

Ask some of your guests to prepare ahead of time! They can download the Canon Print App<sup>3</sup> on their compatible tablet or smartphones (iOS or Android) or download the printer driver on their computer so the driver is ready to install at the party. Download the print driver here >><http://bit.ly/2xMfZtP>

*TIP: Mobile device users should "favorite" the images they want to print or place them in a folder to make it easier to find and print during the party.*

### Match the Paper to the Project

There's a variety of paper in the Party Pack that is perfect for different projects. **Glossy** is great for photos that you want to pop! **Semi-gloss** is great for photos and crafty things that need rich color without a glossy glare, use **matte** for all things crafty-- it's perfect for paper crafts or coloring pages. You'll also get some **restick paper** for decorating or printing out decals and stickers.

*TIP: You can also try a variety of other inkjet printable papers and media such as tattoo paper, fabric iron-on transfers, magnets... and more.*

*Look for "inkjet printable" when you're shopping!*

*TIP: You can ask guests to bring some inkjet printable materials too if they have something specific they want to try and print on.*

### Print Settings

For the best print results make sure to select the correct paper type and size in the print settings when you're printing.

### Ways to Print

 You've got options!

**#1 - From a computer** print using your favorite software or Canon's free My Image Garden<sup>4</sup>. Download the printer driver and software here >><http://bit.ly/2xMfZtP>

**#2 - From a mobile device** to print photos, use the Canon Print App (iOS or Android) 

**#3 - From an SD card** - insert a compatible SD card<sup>5</sup> into the printer and print directly from the screen (just select the images, paper size/type, and print!)

**#4 - Canon cloud printables** - tap on the cloud icon  on the printer screen to setup the Cloud function to print a variety of content such as Coloring Pages and Paper Crafts from the screen!

*more on the back>>*

# Get Crafty with Canon House Party

#CanonParty  
#CraftywithCanon

## Need printer help? Canon is here for you!

Have a technical question or issue? Call the friendly folks at **1-800-OK-CANON** (open Monday-Friday 10:00 am to 10:00 pm ET, excluding holidays). They have all the technical know-how to help!

Like to read? The **User Manual** is packed with all the information you need. Download the User Manual (for Mac or Windows) and have it handy on your computer or device beforehand so you can refer to it during the party. You can download it here >> <http://bit.ly/2kc20ZA>



Now go get #CraftywithCanon  
with your friends and family.

We can't wait to see your  
creativity come to life in print!

<sup>1</sup> Wireless printing and scanning requires a working network with wireless 802.11b/g/n/ac or ad capability. Wireless performance may vary based on terrain and distance between the printer and wireless network clients.

<sup>2</sup> Compatible with iPad, iPhone or iPod touch devices running iOS 9.0 or later, or Android mobile devices running Android 5.1 or later, with Bluetooth hardware enabled. For full print functionality Canon PRINT Inkjet/SELPHY app must be open and paired to use Bluetooth functions, available for free on the App Store and at Google Play. Bluetooth communication and functionality cannot be guaranteed on all Android devices.

<sup>3</sup> Requires an Internet connection and the Canon PRINT Inkjet/SELPHY app, available for free on the App Store and at Google Play. Compatible with iPad, iPhone 3GS or later, and iPod touch 3rd generation or later devices running iOS 7.0 or later, and Android™ mobile devices running Android 2.3.3 or later. Your device must be connected to the same working network with wireless 802.11 b/g/n/ac/ad capability as your printer. May also require a compatible social media account and is subject to that social media account's Terms of Service. Certain exceptions may apply.

<sup>4</sup> To install using Windows® OS, .NET Framework 4 is required. Compatible still image formats are PDF (created using Canon PDF Creator only), JPEG (Exif), TIFF, and PNG. Compatible video formats are MOV (from select Canon digital cameras only) and MP4 (from select Canon digital camcorders only).

<sup>5</sup> Compatible memory cards include SDTM Card, SDHCTM Card. The following can be used with the addition of a special adapter sold separately: miniSDTM Card, miniSDHCTM Card, microSDTM Card, microSDHCTM Card, microSDXCTM Card. Supported File Formats include: JPEG and TIFF (Exif-compliant) taken by DCF(Ver.1.0/2.0) compliant digital cameras. (Exif ver2.2/2.21/2.3 compliant).